


# Industrial Tablet

## STP-800 User Manual





# Catalog

Chapter 1 Product Intro .....	5
1.1 Intro.....	5
1.2 Precaution before using battery.....	6
1.3 Charger.....	7
1.4 Notes .....	8
Chapter 2 Installation instructions.....	9
2.1 Appearance.....	9
2.2 Install Micro SD and SIM cards .....	11
2.3 Battery charge.....	12
Chapter 3 Call function.....	13
3.1 Calling numbers .....	13
3.2 Contacts.....	13
3.3 SMS and MMS.....	13
Chapter 4 Barcode reader-writer .....	14
Chapter 5 RFID reader .....	17
Chapter 6 Other functions .....	18
6.1 PING tool .....	18
6.2 Bluetooth.....	19
6.3 GPS .....	20
6.4 Volume setup .....	21
6.5 Network.....	22
Chapter 7 Device characteristic.....	23



# Chapter 1 Product Intro

## 1.1 Intro

STP-800 device is a industrial tablet that integrated with various features such as UHF RFID, barcode scanning, HF RFID/NFC and fingerprintrecognition etc. It is configured with Andriod 7.1.2 OS and it possesses high reliability and expansibility. With a set of advanced data acquisition options, STP-800 can be operated in various industries toacquire precise and abundant datum automatically. Meanwhile, the device can match the options with staffs accordingly. The corporationwhich deployed STP-800 will realize the deployment work is simple and maintenance work will be remarkably decreased.

STP-800 is highly rugged, compact and durable. With IP65 water and dust proof capability, the device has met IEC sealing standard. Therefore, it can be operated by staffs such as railway inspector, road toll operator, vehicle inspector, delivery postman, power supply inspector,storage administrator, financial & insurance, police officers, security tracing etc. Wherever your staff' locations are, STP-800 can remain its connectivity with the system to make sure business in high-effective operating.

STP-800 industrial tablet adopted 4G LTE technology to realize multipathcommunication and calling function for field work, data exchange efficiency has been enhanced simultaneously. Therefore, STP-800 will bring the largest investment return for enterprises.

## 1.2 Precaution before using battery

- Do not leave battery unused for long time, no matter it is in device or inventory. If battery has been used for 6 months already, it should be checked for charging function or it should be disposed correctly.
- The lifespan of Li-ion battery is around 2 to 3 years, it can be circularly charged for 300 to 500 times. (One full battery charge period means completely charged and completely discharged.)
- When Li-ion battery is not in use, it will continue to discharge slowly. Therefore, battery charging status should be checked frequently and take reference of the related battery charging information on the manuals.
- Observe and record the information of a new unused and non-fully charged battery. On the basis of operating time of new battery and compare with a battery that has been used for long time. According to product configuration and application program, the operating time of battery would be different.
- Check battery charging status at regular intervals.
- When battery operating time drops below about 80%, charging time will be increased remarkably.
- If a battery is stored or otherwise unused for an extended period, be sure to follow the storage instructions in this document. If you do not follow the instructions, and the battery has no charge remaining when you check it, consider it to be damaged. Do not attempt to recharge it or to use it. Replace it with a new battery.
- Store the battery at temperatures between 5 °C and 20 °C (41 °F and 68 °F).

## **1.3 Charger**

The charger type is GME10D-050200FGu, output voltage/current is 5V DC/2A. The plug considered as disconnect device of adapter.

## 1.4 Notes

**Note:**

Using the incorrect type battery has danger of explosion.  
Please dispose the used battery according to instructions.

**Note:**

Due to the used enclosure material, the product shall only be connected to a USB Interface of version 2.0 or higher. The connection to so called power USB is prohibited.

**Note:**

The adapter shall be installed near the equipment and shall be easily accessible.

**Note:**

The suitable temperature for the product and accessories is 0-10°C to 50°C.

**Note:**

CAUTION RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.



# Chapter 2 Installation instructions

## 2.1 Appearance






## Function Guide

1	NFC
2	Power Button
3	SCAN Button
4	Volume Setup
5	Fingerprint
6	SIM/TF Card Slot
7	TYPE-C Port

## 2.2 Install Micro SD and SIM cards

The cards sockets are showing as follows:






## **2.3 Battery charge**



By using USB Type-C contact, the original adaptor should be used for charging the device. Make sure not to use other adaptors to charge the device.

## Chapter 3 Call function





### 3.1 Calling numbers

1. Click icon .
2. Click number key to input phone numbers.
3. Click icon  to call.
4. Click icon  to end call.

### 3.2 Contacts


1. Click contacts to open contacts list.
2. Click icon  to add new contacts.
3. Click icon  to import/export contacts.


### 3.3 SMS and MMS

1. Click  to open message window.
2. Click  to input message receiver and contents.
3. Click  to send out messages.
4. Click  to add attachment pictures and videos.

## Chapter 4 Barcode reader-writer

1. In App Center, to open 2D barcode scan test.
2. Press “SCAN” button or click scan key to start scanning, the parameter “Auto interval” can be adjusted.



 Caution: Please scan codes in correct way otherwise the scanning will be failed.

1D barcode:



Correct



Incorrect

2D code:



Correct



Incorrect



Max. radiant power: 0.6mW

Wave length: 655nm


IEC 60825-1 (Ed.2.0).

21CFR 1040.10 and 1040.11 standard.



## Chapter 5 RFID reader


Click App Center, open “NFC” to read and write tag information.



# Chapter 6 Other functions


## 6.1 PING tool

1. Open “PING” in App Center.
2. Setup PING parameter and select external/internal address.




## 6.2 Bluetooth

1. Open “BT Printer” in App Center.
2. In the list of detected devices, click the device that you want to pair.
3. Select printer and click “Print” to start printing contents.




## 6.3 GPS

1. Click “GPS” in App Center to open GPS test.
2. Setup GPS parameters to access GPS information.



## 6.4 Volume setup

1. Click “Volume” in App Center.
2. Setup volume by requirements.





How to capture screenshot:

Press and hold power button and Volume – at same time.

## 6.5 Network

1. Click "Network" in App Center.
2. Click "Start" to check the IP address and PING information.



## Chapter 7 Device characteristic

### Physical characteristics

<b>Size</b>	250.8mm x 152mm x 15mm/ 9.87 x 5.98 x 0.59in
<b>Weight</b>	700g/24.7oz
<b>Display</b>	8" IPS LTPS 1920x1200
<b>Touch panel</b>	Corning Gorilla Glass 3, multi-touch panel gloves and wet hands supported
<b>Battery</b>	Main battery: Li-ion, rechargeable, 8000mAh
<b>Expansion</b>	Supports up to 32 GB Micro SD card
<b>Expansion Slot</b>	1 slot for SIM card, 1 slot for SIM or TF card
<b>Audio</b>	speaker, 2 microphones, voice call
<b>Camera</b>	13MP autofocus camera with flashlight

### Performance

<b>CPU</b>	2.0GHz MSM8953
<b>OS</b>	Android 7.1.2
<b>RAM</b>	2GB RAM
<b>Communication Interface</b>	USB 3.0 Type-C, OTG
<b>ROM</b>	16GB
<b>Max. expansion</b>	Supports up to 128 GB Micro SD card

### User environment

<b>Operating temp.</b>	-20°C to 50°C
<b>Storage Temp.</b>	-40°C to 70°C
<b>Humidity</b>	5%RH - 95%RH non condensing
<b>Sealing</b>	IP65, IEC sealing standard
<b>Drop specification</b>	Multiple 1.5m/4.9ft drops to concrete across the operating temperature range

## Communication

<b>WWAN</b>	2G: 850/900/1800/1900MHz, GPRS, EDGE 3G: CDMA EVDO:BC0 TD-SCDMA: B34/B39 WCDMA: B1/B2/B5/B8 4G: TDD-LTE: B38/B39/B40/B41 FDD-LTE: B1/B2/B3/B4/B5/B7/B8/B20/B26/B28
<b>WLAN</b>	IEEE802.11 a/b/g/n/ac, 2.4G/5G dual-band internal antenna
<b>WPAN</b>	Bluetooth 4.2/4.1+HS/4.0/3.0+HS/2.1+EDR

## Data collection

<b>Barcode scanning</b>	Zebra SE4710 (standard) Zebra SE4850 (optional)
<b>RFID</b>	NFC 13.56Mhz

## Developing Environment

<b>SDK</b>	software develop kit
<b>Language</b>	Java
<b>Develop</b>	Eclipse/Android Studio